



CAISSON

Measuring equipment

CS-10 Climate sensor



Accessories for meter VI-D4 Climate Sensor for measuring humidity and air temperature.

Instructions:

1. Climate sensor with mini-USB plug and 70 cm cable on the meter in the for plug in the provided socket (USB connection not compatible with USB protocol).
2. Ensure that the airflow through the vents is unobstructed.
3. Read the measured value on the switched-on measuring device. Store the device properly after use to protect the sensors.

Characteristics:

- Air temperature $-10 \sim +50\text{ }^{\circ}\text{C} \pm 0.3\text{ }^{\circ}\text{C}$ (sensor type: thermistor).
- Humidity $5 \sim 95\%$ of relative (RH) $\pm 2\%$ (Sensor type: Capacitive sensor).
- Response time: 5s.